


Vista trasera



SWITCH

Botón 1	Botón 2	Configuración
OFF	ON	232
ON	ON	485
OFF	OFF	422
ON	OFF	422-DROP

Vista delantera

